

01-044-0781-0
01-044-0786-0

Januar 2009

Anleitung Rahmenprotektoren BMW R1200 GS / ADV

Lieferumfang:

1 x Rahmenprotektor rechts
1 x Rahmenprotektor links
13 x Kabelbinder
1 x Streifen Zellgummi

January 2009

Instruction: Frame Protectors R1200GS & R1200GS ADV

Contains:

1 x Frame protector right
1 x Frame protector left
13 x Cable ties
1 x elastic stripes

Achtung: Wichtige Hinweise zur Montage

Es ist empfehlenswert den Rahmen unter dem Protektor mit einem Kratzschutz zu versehen.

Die Rahmenprotektoren werden mit den beiliegenden Kabelbindern am Rahmen befestigt. Achten Sie darauf, dass die Kabelbinder auf der Innenseite / hinten gezogen werden, so dass außen / stiefelseitig eine glatte Oberfläche entsteht.

Versehen sie die Innenseite des Rahmenschutzes an den Befestigungspunkten mit kurzen Zellgummi-Steifen. Enden der Kabelbinder abschneiden!

Attention: important tips, explanations

Finish under cable ties can be protected with tape for example.

Put cable ties thru the holes on the frame protector.

Set the frame protector on the frame and pull cable ties tight. Set the cable tie locks on the inside of the frame so that outside surface stays flat and smooth.

Cut extra lenght on cable tie ends up to the lock.

